
Socket Assembly Spare Parts Kit # I-1001D



POWER ARC PROBE ASSEMBLY

SOCKET ASSEMBLY INSTALLATION INSTRUCTIONS

- Insert wire into connector I1265-2 and crimp.
- Slip Hex Nut I1268 into position over Adapter I1269 as shown.
- Screw Adapter I1269 onto end of ¹/₄" pipe with guide nut.
- Screw opposite end of ot the ¹/₄" pipe into Terminal Casting.
- Thread Wire W12105 through Adapter I1269, Hex Nut I1268,
 ¹/₄" Pipe and Terminal Casting.
- Push Connector I1265-2 and screw Hex Nut I1268 onto Arc Probe.
- Cut Wire W12105 to length (Approximately 3" inside Casting.
- Slip Sleeve W12080 over Wire W12105, leaving 1" exposed.
- Strip Wire W12105.
- Crimp Ring Terminal W12030-10 to Wire W10105 and fasten to Ceramic Stand-Off.

FOR DIRECT SUPPORT

Call (410) 876-3616 Fax (410) 876-9225 info@icimarine.com

